

# Interlift Crane Fork Operating Instructions

The Interlift Crane Fork complies with EC-Machinery Directive 98/37/EC.



| Type             | 1.0 ton      | 1.5 ton      | 2.0 ton      | 3.0 ton      | 5.0 ton       |
|------------------|--------------|--------------|--------------|--------------|---------------|
| loading capacity | 1000 kg      | 1500 kg      | 2000 kg      | 3000 kg      | 5000 kg       |
| weight           | 140 kg       | 165 kg       | 220 kg       | 280 kg       | 380 kg        |
| tine length      | 1000 mm      | 1000 mm      | 1000 mm      | 1000 mm      | 1000 mm       |
| adjustable range | 350 - 900mm  | 350 - 900 mm | 400 - 900 mm | 450 - 900 mm | 500 - 1000 mm |
| useable height   | 1420-1920 mm | 1650-2350 mm | 1655-2355 mm | 1720-2420 mm | 1710-2410 mm  |
| loading height   | 1100-1600 mm | 1300-2000 mm | 1300-2000 mm | 1300-2000 mm | 1300-2000 mm  |
| tines (w x h)    | 100 x 30 mm  | 100 x 40 mm  | 120 x 40 mm  | 120 x 50 mm  | 150 x 60 mm   |

## These Operating Instructions are also applicable for crane forks in special design.

These crane forks are designed for the transport of palletised goods and commodities, which on account of their dimensions - can be safely placed on the tines.

Crane forks may only be attached to lifting appliances (cranes, fork trucks etc.) that are provided with safety hooks.

When using crane forks, the operator has to make sure that the rated capacity (W.L.L.) is not exceeded. The rated capacity applies to a distance of 500 mm between the load's centre of gravity and the stems (half tine length).


The tines have to be adjusted to the width as required by the size of the load and secured by the locking mechanisms.

The useable height of the crane forks can be adjusted to the height of the load within the indicated limits. For this purpose remove the plug-in bolt from the carrying tube and adjust the internal tube to the required useable height. Now replace the plug-in bolt and secure.

With the unloaded crane fork attached to the lifting appliance, the tines have a slight inclination of approx. 3°. This adds to the better entry of the tines into the pallet or under the load. When lifting the load, the suspension eye will automatically move on the upper carrying tube until seated. Two positions for the stop bolt make possible two stop positions of 400 and 500 mm respectively from the carrying tube. Switching over these positions serves to correct the tine settings with respect to the centre of gravity of the load carried.

### **The automatic balancing system requires a minimum load of 20% of the crane fork's rated capacity**

When loaded below 20% of the rated capacity, the suspension eye will not adjust to the load centre – the tines will tilt downwards.



### **The tines may not be tipped forward when the loaded crane forks are raised.**

Outside the immediate area of the floor the load must be secured with a safety chain.

Eyebolts have been installed on the vertical carrying tube for securing the chain.

### **Inspections, precautionary measures and restrictions in the field of applications**

Before initial operation, qualified personnel must inspect the crane forks, and any defects must be remedied. The regular inspections must be conducted in accordance with Sec. 39, 40 and 41 of the regulation for the prevention of accidents. ( Unfallverhütungsvorschrift Lastaufnahmeeinrichtungen im Hebezeugbetrieb VBG 9a).

In order to prevent overloading, the weight of the lifted goods must be determined before the stop is reached and compared with the rated capacity specified on the rating plate.

The lifted goods may not extend beyond the clearance height of the crane forks and the length of the tines.

During transport, severe oscillations and impact with obstacles must be avoided.

The crane forks may transport those goods, which are firmly lashed to the pallets or those commodities whose form and size permit the direct engagement of the tines.

**Persons are forbidden from entering the area beneath the lifted load and the danger zone.**

### **Maintenance**


Damage to paint must be repaired to prevent corrosion. The fork tines must be clean of dirt, oil, grease, and, for outdoor operations, ice.

Repairs to damaged crane forks and the final inspections are to be performed preferably by the manufacturer. In the event of emergencies, however, there are spare parts available for installation by the customer.

Only competent personnel may perform repairs.

Applying to the operation and maintenance are the regulations for the prevention of accidents *Lastaufnahmemittel im Hebezeugbetrieb (load carrying devices in hoisting gear operations VBG 9a in wording of 1 October, 1990.*

## SPARE PARTS



- |    |                                |     |                                     |
|----|--------------------------------|-----|-------------------------------------|
| 1. | Base frame – lower part        | 8.  | Stop bolt with tilting split-pin    |
| 2. | Base frame – upper part        | 9.  | Setting bolt with tilting split-pin |
| 3. | Socket pin with locking device | 10. | Bolt with safety ring               |
| 4. | Tines                          | 11. | Hex nut with split washer           |
| 5. | Suspension lug                 | 12. | Cover                               |
| 6. | Roller                         | 13. | Hex bolt with split washer          |
| 7. | Gas pressure spring            |     |                                     |

To be quoted for spare parts orders please supply type, manufacturing year, and part designation.